

The way the road should be!



ADHESIVE BUTYL PAD

Installation Instructions for installation on Asphalt or Concrete.

Caution: Always wear protective clothing and personal protective equipment (PPE) such as eye protection, work gloves and steel toe work boots while doing the following work.

Note: for optimum performance of the butyl pad, the recommended installation temperature is 50° F or above. When working below 50° F the pad, marker and road surface should be warmed to this temperature prior to installation.

- A clean dry surface is required.
- Sweep or blow off area with compressed air to remove all gravel, sand and other debris within a one foot perimeter of where the marker will be installed.
- Remove the slip sheeting from one side of the pad and place it on the ground with the exposed surface facing up.
- Center the marker on the pad. Press on the marker to secure it to the pad.
- Lift the marker and remove the remaining slip sheet from the other side of the pad.
- Follow manufacturer's instructions as to proper orientation of the marker on the desired location.
Press the marker down firmly onto road surface.
- Slowly drive a vehicle on the marker and stop with a wheel directly on top of the marker.
Allow 15-20 seconds for the marker to set before removing the vehicle.
- Installation is now complete.
Removing: Use scraper and mineral spirits.

www.k-liteusa.com